

# TRIBAR 400 IR

## DMX CONTROL TABLE



2-CHANNEL-MODE		
CHANNEL	VALUE	FUNCTION
CH1	000 - 255	Master-Dimmer (0 - 100%)
CH2	000 - 255	Colour-Macro
	000 - 036	Red
	037 - 073	Green
	074 - 110	Blue
	111 - 147	Yellow
	148 - 184	Magenta
	185 - 221	Cyan
	222 - 255	White

3-CHANNEL-MODE 1		
CH1	CH2	CH3
000 - 017 PG00	000 - 035 Blackout 036 - 255 Colour Macro	000 - 010 No Function  011 - 255 Strobe (slow - fast)
018 - 035 PG01	000 - 255 Speed (slow - fast)	
036 - 053 PG02		
054 - 071 PG03		
072 - 089 PG04		
090 - 107 PG05		
108 - 125 PG06		
126 - 143 PG07		
144 - 161 PG08		
162 - 179 PG09		
180 - 197 PG10		
198 - 215 PG11		
216 - 233 PG12		
234 - 255 Sound Control	000 - 255 Microphone Sensitivity	

**3-CHANNEL-MODE 2**

CHANNEL	VALUE	FUNCTION
CH1	000 - 255	Red (0 - 100%)
CH2	000 - 255	Green (0 - 100%)
CH3	000 - 255	Blue (0 - 100%)

**9-CHANNEL-MODE**

CHANNEL	VALUE	FUNCTION
CH1	000 - 255	Red 1 (0 - 100%)
CH2	000 - 255	Green 1 (0 - 100%)
CH3	000 - 255	Blue 1 (0 - 100%)
CH4	000 - 255	Red 2 (0 - 100%)
CH5	000 - 255	Green 2 (0 - 100%)
CH6	000 - 255	Blue 2 (0 - 100%)
CH7	000 - 255	Red 3 (0 - 100%)
CH8	000 - 255	Green 3 (0 - 100%)
CH9	000 - 255	Blue 3 (0 - 100%)

12-CHANNEL-MODE											
CH1	CH2	CH3	CH4	CH5	CH6	CH7	CH8	CH9	CH10	CH11	CH12
000 - 017 PG00	000 - 035 Blackout/ Colour Mix Ch 4 - 12  036 - 255 Colour Macro										
018 - 035 PG01	000 - 255 Speed (slow - fast)	000 - 010 No Function  011 - 255 Strobe (slow - fast)	Red 1 (0 - 100%)	Green 1 (0 - 100%)	Blue 1 (0 - 100%)	Red 2 (0 - 100%)	Green 2 (0 - 100%)	Blue 2 (0 - 100%)	Red 3 (0 - 100%)	Green 3 (0 - 100%)	Blue 3 (0 - 100%)
036 - 053 PG02											
054 - 071 PG03											
072 - 089 PG04											
090 - 107 PG05											
108 - 125 PG06											
126 - 143 PG07											
144 - 161 PG08											
162 - 179 PG09											
180 - 197 PG10											
198 - 215 PG11											
216 - 233 PG12											
234 - 255 Sound Control	000 - 255 Microphone Sensitivity										